1. Open the front hatch and check where the angle brackets should be placed so that the brackets are centered.
2. The bracket must be mounted on the lowest rib.
3. Open the front hatch and check where the angle brackets should be placed so that the brackets are centered. *(Uwaga: ten punkt w tekście źródłowym jest identyczny z punktem 1)*.
4. Mark on the lowest rib where the holes are to be drilled.
5. Drill through the rib for an M8 bolt.
6. Screw the brackets tight using the included rectangular threaded washers.
7. Mount the long bracket for the auxiliary lights (driving lights) on the front side of the front hatch.
8. Mount the brackets for the plastic knobs that prevent the hatch from opening.
9. Drill a 7mm hole through the front hatch, centered with the molding in the plastic, then adjust the brackets.
10. Ready for mounting the driving lights!





